

AXIS Camera Station Installation and Migration Guide

AXIS Camera Station Installation and Migration Guide

Overview

Overview

AXIS Camera Station is a monitoring and recording system optimized to take full advantage of Axis network cameras and video encoders.

The installation file includes AXIS Cameras Station Client and AXIS Camera Station Server. AXIS Cameras Station Client provides access to recordings and live video. AXIS Camera Station Server handles all communication with cameras, video encoders, and auxiliary devices in the system.

AXIS Camera Station Client can be installed on the same computer as the server and it can also be separately installed on different computers. We recommend that you install AXIS Camera Station Server on a dedicated computer for best performance and stability.

AXIS Camera Station Installation and Migration Guide

Install AXIS Camera Station

Install AXIS Camera Station

When you download AXIS Camera Station you can choose between three different installers:

- An exe file for a full server and client installation. The setup assistant lets you choose between server or client or both.
- An msi file for a full server and client installation.
- An msi file for a client installation only.

Note

- Make sure you have full administrator rights on the computer you want to install AXIS Camera Station on.
 - When you upgrade AXIS Camera Station to a newer version, the background service will stop and there will be no recordings during the upgrade. The background service will start automatically after the upgrade.
1. Go to <https://www.axis.com/products/axis-camera-station/overview>, sign in with your MyAxis account, and download your preferred installer for the latest version of AXIS Camera Station.
 2. Double-click the downloaded file and click **Yes** to allow it to make changes to your device.
 3. Follow the on-screen instructions in the setup assistant.

AXIS Camera Station Installation and Migration Guide

Upgrade AXIS Camera Station

Upgrade AXIS Camera Station

Note

- If your current version is earlier than 4.31.018, you must first upgrade to version 5.24 because the database is upgraded after version 5.24. Then you can upgrade to the latest version.
- If your current version is 4.31.018 or later, you can directly upgrade to the latest version.
- Old SDK support is completely removed since version 5.45. For integrations using the old SDK, contact your integration provider for an upgraded integration.

1. In AXIS Camera Station Service Control, click **Stop** to stop the service.
2. Go to <https://www.axis.com/axis-camera-station/download/list> and download the version you want to upgrade to.
3. *Install AXIS Camera Station on page 3*. Select **Install current version** if you are not installing the latest version.

For more information, see the following files:

- *AXIS Camera Station 5.13 Migration Guide*
- *AXIS Camera Station 5 Migration Guide*

AXIS Camera Station Installation and Migration Guide

Move AXIS Camera Station

Move AXIS Camera Station

After installation of AXIS Camera Station, you can move it to another server and upgrade to a later version at the same time.

When you move an AXIS Camera Station installation, make sure that you use the same Service Control settings on the new server including server name, proxy settings, database backup folder, and ports. If you need certificates, remember to enable them on the new server.

1. Install AXIS Camera Station on the new server. See *Install AXIS Camera Station on page 3*.
 - If the version on the old server is earlier than 4.31.018, you can only install the same version or a version no later than 5.24 on the new server. Because the database must be upgraded to version 5.24 first, then you can upgrade to the latest version.
 - If the version on the old server is 4.31.018 or later, you can install the same version or any later version on the new server.
2. On both servers, go to AXIS Camera Station Service Control and click **Stop** to stop the service.
3. Move the main database files in `C:\ProgramData\AXIS Communication\AXIS Camera Station Server` to the same location on the new server. See *Database files*.
4. If you use AXIS Camera Station Secure Entry, move **SecureEntry.db** in `C:\ProgramData\Axis Communications\Axis Camera Station\Components\Axis Secure Entry` to the same location on the new server.
5. Move your recordings in the recording location specified under **Configuration > Storage > Management** to the same location on the new server.
6. On the new server:
 - 6.1 Start AXIS Camera Station service.
 - 6.2 Start AXIS Camera Station client.
 - 6.3 Log on to the server using the current user or other Windows user.
 - 6.4 Enter password for the devices under **Configuration > Devices > Management**.
7. Register new licenses from the *AXIS License Portal*. See *Move licenses between systems*.

AXIS Camera Station Installation and Migration Guide

Need more help?

Need more help?

Useful links

- *Installation parameters - AXIS Camera Station Microsoft installer*
- *Installation switches - AXIS Camera Station executable*
- *AXIS Camera Station release notes*
- *AXIS Camera Station help center*
- *AXIS Camera Station user manual*
- *AXIS Camera Station tutorial videos*

Contact support

If you need more help, go to axis.com/support.

