

AXIS Camera Station Installation and Migration Guide

AXIS Camera Station Installation and Migration Guide

Overview

Overview

AXIS Camera Station is a monitoring and recording system optimized to take full advantage of Axis network cameras and video encoders.

The installation file includes AXIS Cameras Station Client and AXIS Camera Station Server. AXIS Cameras Station Client provides access to recordings and live video. AXIS Camera Station Server handles all communication with cameras, video encoders, and auxiliary devices in the system.

AXIS Camera Station Client can be installed on the same computer as the server and it can also be separately installed on different computers. We recommend that you install AXIS Camera Station Server on a dedicated computer for best performance and stability.

AXIS Camera Station Installation and Migration Guide

Install AXIS Camera Station

Install AXIS Camera Station

Note

- Make sure you have full administrator rights on the computer you want to install AXIS Camera Station on.
 - When you upgrade AXIS Camera Station to a newer version, the background service will stop and there will be no recordings during the upgrade. The background service will start automatically after the upgrade.
1. Go to <https://www.axis.com/products/axis-camera-station/overview>, sign in with your MyAxis account, and download the latest version of AXIS Camera Station.
 2. Double-click the downloaded file and click **Yes** to allow it to make changes to your device.
 3. Select the language to install and click **OK**. If you are prompted to install .NET Framework. Follow the Installation Wizard's instructions.
 4. Read the license agreement, select **I accept the agreement** and click **Next**.
 5. Select where to install or accept the default folder. Click **Next**.
 6. Select the components to install. If you want to install AXIS Camera Station Server on another computer, you can select to install only AXIS Camera Station Client. Click **Next**.
 7. Decide whether to **Add exceptions for AXIS Camera Station to the Windows Firewall**, create a desktop icon and share your anonymous usage data. Click **Next**.
 8. Read the information about activating Windows NTP Server and click **Next**.
 9. Click **Install** and click **Finish** when the installation is done.

AXIS Camera Station Installation and Migration Guide

Upgrade AXIS Camera Station

Upgrade AXIS Camera Station

Note

- If your current version is earlier than 4.31.018, you must first upgrade to version 5.24 because the database is upgraded after version 5.24. Then you can upgrade to the latest version.
- If your current version is 4.31.018 or later, you can directly upgrade to the latest version.
- If you use AXIS Camera Station Secure Entry, make a manual backup of `SecureEntry.db` before upgrading. See *Back up database*.

1. In AXIS Camera Station Service Control, click **Stop** to stop the service.
2. Go to <https://www.axis.com/axis-camera-station/download/list> and download the version you want to upgrade to.
3. *Install AXIS Camera Station on page 3*. Select **Install current version** if you are not installing the latest version.

For more information, see the following files:

- *AXIS Camera Station 5.13 Migration Guide*
- *AXIS Camera Station 5 Migration Guide*

AXIS Camera Station Installation and Migration Guide

Move AXIS Camera Station

Move AXIS Camera Station

After installation of AXIS Camera Station, you can move it to another server and upgrade to a later version at the same time.

When you move an AXIS Camera Station installation, make sure that you use the same Service Control settings on the new server including server name, proxy settings, database backup folder, and ports. If you need certificates, remember to enable them on the new server.

1. Install AXIS Camera Station on the new server. See *Install AXIS Camera Station on page 3*.
 - If the version on the old server is earlier than 4.31.018, you can only install the same version or a version no later than 5.24 on the new server. Because the database must be upgraded to version 5.24 first, then you can upgrade to the latest version.
 - If the version on the old server is 4.31.018 or later, you can install the same version or any later version on the new server.
2. On both servers, go to AXIS Camera Station Service Control and click **Stop** to stop the service.
3. Move the main database files under `C:\ProgramData\AXIS Communication\AXIS Camera Station Server` to the same location on the new server. See *Database files*.
4. If you use AXIS Camera Station Secure Entry, move **SecureEntry.db** under `C:\ProgramData\Axis Communications\AXIS Camera Station Secure Entry Service` to the same location on the new server.
5. Move your recordings in the recording location specified under **Configuration > Storage > Management** to the same location on the new server.
6. On the new server:
 - 6.1 Start AXIS Camera Station service.
 - 6.2 Start AXIS Camera Station client.
 - 6.3 Log on to the server using the current user or other Windows user.
 - 6.4 Enter password for the devices under **Configuration > Devices > Management**.
7. Register new licenses from the *AXIS License Portal*. See *Move licenses between systems*.

AXIS Camera Station Installation and Migration Guide

Need more help?

Need more help?

Useful links

- *AXIS Camera Station help center*
- *AXIS Camera Station User Manual*

Contact support

Contact support at axis.com/support.

