

User manual

Store recordings in the cloud

Store recordings in the cloud

AXIS Camera Station Cloud Storage offers a way to store your recordings in the cloud. To configure cloud storage:


- 1. Enable the connected services on your devices. See Enable connected services on your devices in the AXIS Camera Station Edge user manual for more information
- 2. Activate cloud storage for the organization. See for more information.
- 3. Turn on cloud storage for your individual cameras. See for more information.

For AXIS Camera Station Cloud Storage to connect to required services, you need to allow some traffic in the firewall. See for more information.

Store recordings in the cloud


Activate cloud storage for an organization

1. Open the My Systems menu



Store recordings in the cloud

2. Open




Cloud storage.

3. Click Activate and follow the on-screen instructions.

Store recordings in the cloud


Turn on cloud storage for your individual cameras

1. Open the My Systems menu



Store recordings in the cloud

2. Open



Cloud storage.

- 3. Select the cameras that you want to turn on cloud storage for.
- 4. Click Turn on cloud storage.
- 5. Click Confirm.

Firewall configuration

For AXIS Camera Station Cloud Storage to connect to required services, you must allow the following URLs in the firewall:

- *.connect.axis.com
 - prod.keyserver.vms.connect.axis.com
 - prod.cloudstorage.vms.connect.axis.com

Store recordings in the cloud

- *.wasabisys.com
 - *.s3.<region>.wasabisys.com

<region></region>	Description
ap-southeast-2	Australia
ca-central-1	Canada
eu-central-2	EU
eu-west-1	UK
us-east-1	US

User manual AXIS Camera Station Cloud Storage © Axis Communications AB, 2024 Ver. M1.2 Date: November 2024 Part no. T10217677