

User manual

Table of Contents

Introduction			٠.					
Get started			• •	•	•	•	• •	• -
Get started Register a My Axis account	• • •	• • •	• •	• •	• •	•		• ! • !
Install the hardware			• • •	• •	٠.	•	٠.	. ;
Install the hardware		• • •			٠.	•	٠.	
Install the desktop app			• • •		٠.	•		. (
Create a site			• • •		٠.	•		٠ '
install the mobile app			• • •		٠.			
Daily use								. 8
Access your devices								. 8
View live video								
Play a recording								. 8
Save a recording								. 8
Take a snapshot								. (
Adjust the image settings								. 10
View events								10
Configuration								. 12
Configure the video quality	• • •	• • •	• •	•	•	•	• •	. 12
Configure the video quality Configure video motion detection				•	• •	•	٠.	. 12
Cot up notifications			• • •	•	٠.	•	٠.	. 13
Set up notifications			• • •	•	• •	•		. 1
Use intercoms	• • • •	• • •	• • •	• •	٠.	•	٠.	. !
Use network speakers Use strobe sirens				٠.	٠.	-	٠.	. 14
Use strobe sirens					٠.			. 14
Add a user								. 14
Add a device to your site								. 1
Remove a device from your site								. 10
Remove a device from your site								. 10
Replace a device in your site								. 10
Replace a device in your site								. 13
Activate offline mode								. 17
Maintenance				٠.				. 19
Manage your system remotely			•	•	•	-	• •	. 19
Manage your system remotely			• • •	•	٠.	•	٠.	. 2
Hard reset a device				٠.	• •	•	٠.	. 2
Hard reset a recorder			• • •	•	٠.	•		. 24
The mobile app		• • •	• • •	• •	٠.	•		. 2
Oranian	• • •	• • •	• •	•	• •	•	• •	. 2:
Overview				٠.	٠.		٠.	. 2
Turn on notifications					٠.			. 2
Add a device in the mobile app					٠.			. 2
Create a site in the mobile app								. 20
The TV app								. 2
Show video on an external display								. 2
Troubleshooting								. 28
Troubleshooting			•	•	•	-	• •	. 28
Technical issues, clues and solutions			• • •	•	• •	•		. 28
Cove a system report			• • •	• •	٠.	•	• •	. 30
Save a system report				٠.	٠.	•		. 30
Migrating from AVIC Companies Classic to		• • •			٠.	•	٠.	. 31
Migrating from AXIS Companion Classic to								. 3

Introduction

Introduction

This manual describes how to use version 4.0 and later.

Are you currently using AXIS Companion Classic?

• To upgrade to the latest version, see *Migrating from AXIS Companion Classic to on page 31*.

System recommendations

System recommendations

• OS: Windows 10 64-bit

• CPU: Intel Core i5

• RAM: 4 GB

• Graphics card: 256 MB onboard video memory

• Graphics card driver: Always use the latest version

• Network: 100 Mbps

• Internet access is required during system setup and management (live and recorded video available offline)

• Uninterruptible Power Supply (UPS)

• Mobile devices: iOS 15 or Android 8.1

If you are using devices with firmware 5.50, see Using devices with firmware 5.50 on page 30.

Get started

Get started

Note

Internet access is required during the system setup.

- 1. Register a My Axis account on page 5
- 2. Install the hardware on page 5
- 3. Install the desktop app on page 6
- 4. Create a site on page 6
- 5. Install the mobile app on page 7

When the installation is done:

- All Axis devices in the system have the latest firmware.
- All devices have a password.
- Recording using the default settings is active.
- You can use remote access.

Register a My Axis account

Register a My Axis account at axis.com/my-axis/login.

To make your My Axis account more secure, activate multi-factor authentication (MFA). MFA is a security system that adds another layer of verification to ensure the user's identity.

To activate MFA:

- 1. Go to axis.com/my-axis/login.
- 2. Log in with your My Axis credentials.
- 3. Go to and select Account settings.
- 4. Click Security settings
- 5. Click Handle your 2-factor authentication.
- 6. Enter your My Axis credentials.
- 7. Choose one of the authentication methods Authenticator App (TOTP) or Email and follow the on-screen instructions.

Install the hardware

Before you install the hardware:

- Make sure you have internet access.
- Make sure you use the same network for your computer and the devices your are going to install.
- Hard reset any devices that were previously used in another system.

Get started

Use an AXIS S30 Series Recorder as recording device

- 1. Connect the AXIS S30 Series Recorder to your network through the LAN port.
- 2. Mount your devices and connect them to the recorder's PoE ports.
- 3. Connect the power supply to the recorder.
- 4. Wait a few minutes for the recorder and devices to boot up before proceeding.

▲CAUTION

Keep the recorder in a well ventilated environment and with plenty of empty space around the it to avoid overheating.

You can find more information about the recorder, such as power requirements and how many devices you can connect, in the documentation on the recorder's support page on axis.com.

Use an AXIS Surveillance Card as recording device

- 1. Connect a PoE device, such as a PoE switch, to your network.
- 2. Insert an AXIS Surveillance Card into the devices you wish to record from.
- 3. Mount your devices and connect them to the PoE device.
- 4. Wait a few minutes for the devices to boot up before proceeding.

Install the desktop app

- 1. Go to axis.com/products/axis-companion and click Download to download for Windows.
- 2. Open the setup file and follow the setup assistant.
- 3. Sign in with your My Axis account.

Create a site

A site is a single point of entry to a surveillance solution, for example all cameras in a store. You can keep track of several sites through a single My Axis account.

Note

If you've used an earlier version of , the sites you created won't appear in the list of sites in . You might also have devices that aren't supported. See *Migrating from AXIS Companion Classic to version 4* for more information.

- 1. Start the desktop app.
- 2. Sign in with your My Axis account.
- 3. Click Create new site.
- 4. Name your site and enter your company name.
- 5. Click Next.
- 6. Select the devices you want to add to your site.
- 7. Click Next.
- 8. Select storage.
- 9. Click Next.

Get started

- 10. On the Ready to install page, Offline mode and Upgrade firmware are turned on by default. You can turn them off if you don't want to access offline mode or upgrade your devices to the latest firmware version.
- 11. Click Install and wait while configures the devices.

The configuration can take several minutes.

Install the mobile app

With mobile app, you can access your devices and recordings from anywhere. You can also get notifications when events occur, or when someone calls from an intercom.

For Android

Click Download or scan the following QR Code®.



For iOS

Click Download or scan the following QR Code.



Open the mobile app and log in with your Axis credentials.

If you don't have a My Axis account, you can go to axis.com/my-axis to register a new account.

QR Code is a registered trademark of Denso Wave Incorporated in Japan and other countries.

Daily use

Daily use

Access your devices

- 1. Sign in to on a computer or a mobile device using your My Axis account.
- 2. Enter the site that contains your devices.

View live video

- 1. Go to
- 2. Select which camera you want to view.

View live video in a grid

- 1. Go to
- 2. Click , or right-click in the image and select Show split view.

To go back, right-click in the split view and select Exit split view.

View live video in a sequence

- 1. Go to
- 2. Click , or right-click in the image and select Show split view.
- 3. Right-click in the split view and select **Show as sequence**.

To go back, right-click in the sequence view and select Exit sequence view.

Play a recording

- 1. Go to
- 2. Use the timeline and calendar to find the recording.
- 3. Select the camera in the timeline and move the playback marker to the desired time.

Note

When you move the playback marker, the video image is updated continuously. This makes it easy for you to find a specific moment in the recording.

4. Click Play.

Save a recording

Daily use

- 2. Select start and end times for a recording.
- 3. Select which devices to save recordings from.
- 4. To save to a USB drive on an AXIS S30 Series Recorder, select the Save to recorder USB checkbox.

Note

The first partition of your USB device must use an exFAT or NTFS file system.

5. Save the recording.

Change the location of your saved recordings:

- 1. Go to Settings > File.
- 2. Change the location under Recordings.

Play a saved recording

To play a saved recording, open it with AXIS File Player.

When you save a recording, the AXIS File Player will be saved in the same folder. The AXIS File Player has a timeline showing what time the recording was made.

Validate a saved recording

You can validate a recording to confirm that the timestamp and images have not been manipulated after the recording was first saved. For this purpose, a digital signature will be included in the file when you save a recording. You can add a password to the digital signature for increased security.

To protect your digital signature with a password when saving a recording:

- 1. Go to Settings > File.
- 2. Under Video format, select Windows Media Format (.asf).
- ${\it 3.} \quad {\it Select Show digital signature options when saving recordings}.$

Next time you save a recording, the **Digital signature** window appears, which allows you to select a password for the signature.

Validate a recording:

- 1. Open the saved recording with AXIS File Player.
- 2. Click Tools and select Verify digital signature.
- 3. Enter the password, if a password was added to the signature, and click **OK**.

A window appears to inform whether or not the recording is valid.

Take a snapshot

Take a snapshot from live view:

- 1. Go to
- 2. Click

Daily use

Take a snapshot from recordings:



- 2. Use the timeline and calendar to find the recording.
- 3. Select the camera in the timeline and move the playback marker to the desired time.
- 4. Click to start investigation mode.
 - Investigation mode allows you to step through the recorded video, frame by frame, to find the exact moment when an incident happened and take a snapshot from that moment.
- 5. To find the incident, click on the thumbnails to step 30, 15, 5 or 1 frames backward (top panel) or forward (bottom panel). You can also move the slider.
- 6. When satisfied, click to take a snapshot.
 - For most cameras the snapshot will contain the entire camera image, regardless of the zoom level. For cameras with a dewarped image, the snapshot will be the zoomed-in image.

Change the location of your saved snapshots:

- 1. Go to Settings > File.
- 2. Change the location under Snapshots.

Adjust the image settings

- 1. Go to Cameras > Image.
- 2. Select the camera you want to adjust.

You can control the image by adjusting settings like:

- Appearance
- Exposure
- Overlays
- Day & night
- · Privacy mask
- Focus & zoom

View events

You can view a list of events that have been detected by your devices.

- 1. Click to see the list of events.
- 2. Click on a specific event in the list to see a recording of it.
- 3. Right-click on a specific event in the list and select Go to live view to go to the live view of the device that triggered it.

Daily use

To see events in the list and get notifications when they occur, you need to set up event notifications.

- To set up event notifications based on built-in motion detection, see *Configure video motion detection on page 12*.
- To set up event notifications based on other Axis analytics applications, see the **How to** articles on axis.com/products/axis-companion-4/support.

Example:

A receptionist pushes a panic button. An operator is notified and views the event.



To watch this video, go to the web version of this document.

help.axis.com/?&piald=53506&tsection=view-events

With reservations for changes in the user interface.

Configuration

Configuration

Configure the video quality

You can configure the video quality to suit your image quality requirements and bandwidth usage. Video quality settings affect motion recording, continuous recording and the live view.

- 1. Go to Cameras > Video quality.
- 2. Select the camera you want to configure.
- 3. Edit the Resolution and/or the Frame rate in the high or low profile.
- 4. Click Apply to save.

Configure video motion detection

When you set up system, continuous recording is the recording method that is automatically configured. Continuous recording is most advantageous if you use it together with event notifications based on video motion detection.

Send event notifications based on motion detection to your desktop app:

- 1. Go to > Events > Video Motion Detection.
- 2. Set up a schedule.
- 3. Under Activation, select the devices you wish to get a notification from.

If the motion detection is triggered too often, you can adjust the settings to ignore parts of the view or certain types of events.

- 1. Go to Recordings settings > Video motion detection.
- 2. Select the camera you want to adjust.
- 3. Select which part of the camera view to include or exclude during motion detection.
 - Edit the predefined area to include during motion detection.
 - Select Exclude areas and edit the area to exclude from motion detection.

Note

For some camera models you can only add rectangular shapes, and for others you can add polygons.

- 4. Expand Advanced to adjust the settings of the filters.
 - Small objects filter: Ignore small objects, such as animals.
 - **Swaying objects filter:** Ignore objects that only move within a short distance, such as trees or flags that move when it is windy.

Note

The swaying objects filter is not available for all camera models.

Short-lived objects filter: Ignore objects that only appear briefly in the image, such as light beams from passing cars or fast-moving shadows.

To turn on event notifications in mobile app, see Turn on notifications on page 25.

Configuration

If you want to turn off continuous recording and only record when motion is detected, see *Record only when motion is detected on page 13*.

Record only when motion is detected

If you don't want to use continuous recording as recording method in your system, you can configure to only record when motion is detected.

- 1. Go to Cameras.
- 2. Turn off Continuous recording for your devices.
- 3. Turn on Motion detection for the device/s of your choice.

For more information about motion detection, see Configure video motion detection on page 12.

Set up notifications

You can configure to send notifications to your desktop and mobile app.

- To set up event notifications based on built-in video motion detection, see Configure video motion detection on page 12.
- To set up event notifications based on other Axis analytics applications, see the How to articles on axis.com/products/axis-companion-4/support.
- To turn on event notifications in mobile app, see *Turn on notifications on page 25*.

Use intercoms

Add intercoms to your video surveillance system to be able to answer calls from your desktop or mobile app, and to unlock doors.

Note

To unlock a door, your intercom must be properly connected to the door's electronic lock. The documentation for your intercom contains information about how to make this connection correctly. To find the documentation for your intercom, go to axis.com/products/axis-network-intercoms

Adjust the output gain

You can adjust the output gain for the intercom ringtone and calls.

- 1. Go to Cameras > Intercom.
- 2. Select the intercom you want to adjust.
- 3. Adjust the number of dB under Output gain.
- 4. Click Apply.

Manage call timeout

You can decide how long an unanswered call should ring before it's automatically declined.

- 1. Go to > > Cameras > Intercom.
- 2. Select the intercom you want to adjust.
- 3. Adjust the number of seconds under Calling timeout.

Configuration

4. Click Apply.

Adjust unlock duration

You can decide how long a door should remain unlocked after you open it through .

- 1. Go to Cameras > Intercom.
- 2. Select the intercom you want to adjust.
- 3. Edit the number of seconds under Unlock duration.
- 4. Click Apply.

Use network speakers

Add speakers to your video surveillance system to improve the security on your premises by using event-triggered announcements and direct callouts.

Note

- For information about how to adjust speaker volume and use event-triggering, see the user manual for your speaker. You can find the user manual on the product's support page on axis.com or on help.axis.com.
- If you want to use multiple speakers, use AXIS Audio Manager Edge to group them in zones. You can find the user manual for AXIS Audio Manager Edge on the support page or on help.axis.com.
- For information about how to use Axis network speakers to play pre-recorded announcements in , see the **How to** article on axis.com/products/axis-companion-4/support.

Send live announcements

In , a push-to-talk function makes it possible to send live announcements to one or several speakers.

Send an announcement to a speaker:

- 1. Go to and select the camera of your choice.
- 2. Select your speaker.
- 3. Press and hold the mic icon to activate the microphone.
- 4. When you have sent your announcement, release the mic icon.

If you want to send an announcement to multiple speakers, use AXIS Audio Manager Edge to group your speakers and add them to a zone before you send your announcement.

Note

You can find the user manual for AXIS Audio Manager Edge on the product's support page or on help.axis.com.

Use strobe sirens

Add strobe sirens to your video surveillance system to improve the security on your premises by using event-triggered signals and alarms.

Note

- For information about how to set up a strobe sire, see the user manual for your strobe siren. You can find the user manual on the product's support page on axis.com or on help.axis.com.
- For information about how to use AXIS D4100-E Network Strobe Siren in , see the How to article on axis.com/products/axis-companion-4/support.

Configuration

Add a user



2. Click Add....

3. Type an email address and select an access level.

4. Click OK.

The user receives an email with instructions on how to get started. The final step is to accept the invitation. See *Accept an invitation on page 15* for more information.

Note

If you add a user who doesn't have a My Axis account, the user will be asked to create an account.

The following access levels are available:

Administrator	Full access
Operator	Can access recordings and live view, but can't make any changes to the site
Viewer	Can only access live view

Accept an invitation

When you receive an invitation to a site, you must first accept the invitation before accessing the site.

- 1. Go to > Invitations.
- 2. Click Accept.
- 3. Click Close when you're done.

Add a device to your site

1. Connect the device to the recorder's PoE ports or to an external PoE switch.



- 3. Click Add devices.
- 4. Select the device you want to add to your site.
- 5. Click Next.
- 6. Enter a password.

Use this password to access the web interface of your device or offline mode in mobile app.

7. Click Next.

Configuration

- 8. On the Ready to install page, Offline mode and Upgrade firmware are turned on by default. You can turn them off if you don't want to access offline mode or upgrade your devices to the latest firmware version.
- 9. Click Install and wait while configures the device.

The configuration can take several minutes.

Remove a device from your site

1. Go to Cameras or > Other devices.

To remove a recorder, see Remove a recorder from your site on page 16.

- 2. Click > Remove next to the device you want to remove.
- 3. Click OK.

If the device is connected to a recorder, you need to select if you want to remove the recordings from the recorder.

Remove a recorder from your site

Note

Before you can remove a recorder, you need to change the storage option of the devices that are connected to it.

Change the storage option:

- 1. Go to Cameras > Storage.
- 2. Select the device you want to change.
- 3. Select No storage.
- 4. Click Apply.

Remove the recorder:

- 1. Go to Recorders.
- 2. On the row of the recorder you want to remove, click > Remove.
- 3. Click OK.

Replace a device in your site

If you need to replace a device that is connected to a recorder, you may want to save the recordings before removing and replacing the device. Once the device has been removed from the site, the recordings will no longer be available in the **Recordings** area in .

Save your recordings:

- 1. Go to 😂 >
- 2. Select which device you want to save recordings from.

can save up to 24 hours of recorded material at a time.

Configuration

Remove the device:

- 1. Go to Cameras.
- 2. Click > Remove next to the device you want to remove.
- 3. In the dialog that appears, select Remove recordings from recorder.

If you do not select this option, the recorder will not free up the associated recording slot, and other devices will not be able to connect to the same slot.

To add a replacement device, see Add a device to your site on page 15.

Replace a recorder in your site

Before you can replace a recorder in your site, you need to remove the devices that are associated with it.

Remove devices:

- 1. Go to Cameras > Storage.
- 2. Select the device you want to change.
- 3. Select No storage.
- 4. Click Apply.

Repeat for all of the devices that are connected to the recorder you would like to replace.

To remove the recorder, see Remove a recorder from your site on page 16.

Add a new recorder to your site:

- 1. Follow the steps in Add a device to your site on page 15.
- 2. Go to Cameras > Storage.
- 3. Select the device you want to edit.
- 4. Select the new recorder from the list.
- 5. Click Apply.

Activate offline mode

If you activate offline mode, you can run with limited functionality even if the internet connection temporarily goes down. You will be able to access Live view and Recordings locally without internet connection, but not the Configuration menu to make changes to your site.

To activate offline mode:

- 1. Go to Site.
- 2. Turn on Offline mode.

Configuration

Note

- The site must be online when you turn on offline mode. Each Windows user must turn on offline mode for their clients.
- Offline mode is not intended for permanent use. Connect your system to the internet at least every three months to update the firmware and certificates of your devices.
- The computer that accesses the site in offline mode should be connected to the same subnet as the devices. You can't use offline mode if your client is connected to the internet.
- The mobile app will use the same password as was set for the device when the site was created.
- You will not be able to get a full system report without internet connection.
- For sites that will be used mostly offline, we recommend you to set them up with static IP or DHCP reservation.

Maintenance

Maintenance

Manage your system remotely

Remote access to a surveillance system can save a lot of time and money during maintenance and troubleshooting. With remote access, you will get an overview of the installations and can undertake simple maintenance steps right away, such as:

- Restart devices
- · Upgrade devices
- Manage user permissions

Get started with remote management

Note

Only users with administrator rights have access to the sites.


- 1. Go to connect.axis.com
- 2. Log in to your My Axis account to see a list of your sites.



ML

Sites






- To find a site, type in the search field.
- To only display sites that contain errors, click Has error.
- To sign out, click the initials menu and Sign out.

Maintenance

Manage sites



Invite a user to a site:

- 1. Click > Users.
- 2. Click Add a user to a site.
- Type the e-mail address of the user and select a permission level
 To read more about the different permissions, see Add a user on page 14.
- 4. Click Invite.

Remove a user from a site:

- 1. Click > Users.
- 2. Click > Remove from site.

Rename a site:

- 1. Click > Rename.
- 2. Type the new name and click Rename

Remove a site:

1. Click > Remove.


You need to remove the devices in your site before you can remove it.

2. Click Delete to confirm.

Maintenance

Manage devices

When you click on a site, you will see a list of all of the included devices.



Upgrade the firmware for a single device:

- 1. Click on the device to see its properties.
- 2. Click Upgrade.

Upgrade the firmware for all devices:

1. Click Upgrade all.

The option is only visible when there are several available firmware updates.

Note

A firmware upgrade can take several minutes.

Rename a device:

- 1. Click > Rename.
- 2. Type the new name and click Rename

Restart a device:

1. Click > Restart.

Maintenance


2. Click Restart to confirm.

Delete a device:

- 1. Click > Delete.
- 2. Click Delete to confirm.

Upgrade firmware


Upgrade the firmware of your devices regularly to get the latest features and security updates.



2. Click Upgrade firmware.

Maintenance

3. Select the devices that you want to upgrade.



4. Click OK.

The upgrade can take several minutes.

Hard reset a device

Note

- A hard reset will not affect your recordings.
- A hard reset will reset all the settings, including the IP address.
- 1. Select the device you want to hard reset and remove it from the site.

See Remove a device from your site on page 16.

- 2. Disconnect the power from the device.
- $\ \, 3.\ \,$ Press and hold the control button on the device, and then reconnect the power.

Keep the control button pressed for 15–30 seconds until the status LED indicator flashes amber.

4. Release the control button.

The process is complete when the status LED indicator turns green.

The product has now been reset to the factory default settings.

5. Add the device to the site again.

Maintenance

See Add a device to your site on page 15.

Hard reset a recorder

Important

Move the recorder carefully while it's switched on. Sudden moves or shocks may damage the hard drive.

Note

- A hard reset will reset all the settings, including the IP address.
- A hard reset will not remove your recordings.
- A hard reset will not remove the encryption password.
- 1. Switch off the recorder:

Press the power button on the front of the recorder for 4-5 seconds until you hear a beep.

- 2. Wait until the recorder is switched off, then turn it over to access the control button.
- 3. Press and hold the control button. Press and release the power button to start the recorder. Release the control button after 15–30 seconds when the LED indicator flashes amber.
- 4. Carefully put the recorder back in its place.
- 5. The process is complete when the status LED indicator turns green. The product has been reset to the factory default settings. If no DHCP server is available on the network, the default IP address is 192.168.0.90
- 6. Reset your devices connected to the recorder.

When you add your recorder to a site after a hard reset, you will be asked to type your encryption password to unlock the recorder, or to click Format disk to set a new password.

The mobile app

The mobile app

With mobile app, you can access your devices and recordings from anywhere. You can also get notifications when suspicious events occur, or when someone calls from an intercom.

To download the mobile app to your Android or iOS device, see *Install the mobile app on page 7*.

Overview

The mobile app contains many of the features and settings that are available in the desktop app. Use these four tabs to access and make changes to your sites.

- Video: Where you access the live view and recordings of your devices, switch sites if you have access to more than one, or create new sites.
- Events: Where you find the list of events that have been detected by your devices. Click on a specific event to see a recording of it.
- Devices: Where you access the settings of your devices. For example, you can upgrade the firmware, change the recording method and add or remove a device.
- More...: Where you manage users and notifications, change the theme or get help if you run into issues.

Turn on notifications

You can get notifications to your mobile app when different events occur, for example when motion is detected, or when someone calls from an intercom.

To turn on notifications

- 1. Turn on notifications for mobile app in your mobile device's notification settings.
- 2. Open mobile app.
- 3. Go to More > O > Notifications.
- 4. Select the notifications you want to turn on or off.

Add a device in the mobile app

Note

Make sure your mobile is connected to the same network as your devices and your computer running the desktop app.

- 1. Go to Devices.
- 2 Click +
- 3. Select the devices you want to add.
- 4. Click Next.
- 5. Enter a password.

Use this password to access the webpages of the devices or offline mode in the mobile app.

6. Click Next and wait while configures the device.

The mobile app

The configuration can take several minutes.

Create a site in the mobile app

Note

Make sure your mobile is connected to the same network as your devices and your computer running the desktop app.

- 1. Log in to your My Axis account.
- 2. If you have sites associated with your My Axis account: Click on the site name in the top left corner.

 If you don't have sites associated with your My Axis account: Click Welcome in the top left corner.
- 3. Click +
- 4. Click Next.
- 5. Name your site and click Next.
- 6. Add your company name and click Next.
- 7. Select the devices you want to add to your site and click Next.
- 8. Enter a password for your devices.Use this password to access the webpages of your devices or to access offline mode in the mobile app.
- 9. Click Next.
- 10. Verify that the site details and devices you have added are correct and click Next.
- 11. Wait while configures the devices.

The configuration can take several minutes.

The TV app

The TV app

Show video on an external display



To watch this video, go to the web version of this document.

help.axis.com/?&tpiald=53506&tsection=show-video-on-an-external-display

With reservations for changes in the user interface.

What you need:

- app installed on your mobile device.
- TV app installed from the app store on your Apple TV or Android TV device.
- Your cameras, mobile app and TV app must all be connected to the same local network.
- AppleTV 4 and Nvidia Shield with Android 6 or later.

This is how you do it:

- 1. Open mobile app and log in.
- 2. Go to Devices > and select your external display.

Note

It may take a few seconds before the icon appears.

- 3. Select the cameras you want to show on your external display.
- 4. Tap and wait for the configuration to complete.
- 5. You can view a single camera at a time or create a split view with up to 16 cameras.
- 6. When TV app opens, read the instructions on the screen about how to navigate in the app.

Troubleshooting

Troubleshooting

software is designed to be used with new devices, or with devices where previously modified settings have been restored. If you add devices to that have been used in previous systems, make sure to hard reset them before you add them to your site. Modifications of device settings that are not available in can in some cases affect your system and impact the performance.

Furthermore, always make sure that your client and Axis devices are updated with the latest software and firmware updates.

Visit axis.com/products/axis-companion for information such as:

- Datasheet
- Compatible products
- Support and resources

Get notifications on the status of Axis services

If you're experiencing general problems in , you can check the status of the Axis services to rule out any incidents or scheduled maintenance.

- 1. Go to https://status.axis.com/.
- 2. Expand to view the status of the different functions.

To subscribe and get notifications on the status of Axis services:

- 1. On https://status.axis.com/, click SUBSCRIBE TO UPDATES.
- 2. Enter your email address.
- 3. Click SUBSCRIBE VIA EMAIL.
- 4. Select the individual components you're interested in.
- 5. Click Save.
- 6. Open the email from Axis status and click Confirm subscription.

Technical issues, clues and solutions

Site creation	
No devices are detected	Check that your devices have power and are connected to the same subnet as your computer.
The devices are not supported	Older Axis devices with a firmware that can't be updated to 5.50 or later are not supported.
Communication errors	couldn't contact the device. Possible reasons:
	Unstable connection to the internet. Make sure you

- Unstable connection to the internet. Make sure you have internet connection and try again.
- The device is not available on the network after restarting, restoring or upgrading the firmware.
 Close the wizard and wait a few minutes before you restart it.
- The device doesn't have the expected settings, which prevents from communicating with the device. Close the wizard, hard reset the device and start the wizard again.

Troubleshooting

Site creation	
	 The use of VPN or additional network security features block the connection to Axis services. Make sure that required addresses are excluded from inspection and allowed by the firewall. For more information, see this FAQ.
Login	
The username or password is incorrect	The username and password combination is not valid.
The site is not available	 Make sure the computer with your client is connected to the network. Make sure that no firewall or antivirus software blocks the internet connection. For more information, see this FAQ. Check status.axis.com for incidents or scheduled maintenance of Axis services.
Live view	
There is no video	 Make sure your system follows the recommendations listed in System recommendations on page 4. Make sure your graphic card is updated with the latest driver.
The video is lagging	 Make sure your system follows the recommendations listed in System recommendations on page 4. Make sure your graphic card is updated with the latest driver.
No contact	The device can't be accessed on the network. Check that your devices have power and internet connection.
Unable to retrieve stream	Make sure that you don't request too many streams from the cameras. See the troubleshooting section in the user manual of each individual camera at <i>help.axis.com</i> .
Configuration workspace	
Communication error	The connection to the device is temporarily lost. If you click on the link that appears, tries to repair the connection. Make sure that the device is available on the network with valid network settings.
Configuration error	The device doesn't have the expected settings or is configured inaccurately. If you click the link, tries to repair the error. If the attempt fails, hard reset the device and add it to the site again.
No contact	The device is no longer available on the network. Check that the device/recorder has power and access to the internet.
Storage error	The device can't contact the recorder. Make sure IPv6 is enabled for your devices (uses IPv6 for communication).

Troubleshooting

Storage error	There are issues with the recording media, for example a missing SD card, faulty disk or incorrect configuration.			
	 Go to Configuration in and refresh the connection. Check that your recording media doesn't report any errors. See the user manual for your recording device for more information. You can find the user manual at help.axis.com. 			
Can't access the recorder	The recorder is offline. Make sure it has power and internet connection.			
Intercoms				
Intercom calls are not coming through	Check that your client (computer or mobile phone) has internet connection.			
Can't unlock the door	Make sure the intercom is correctly wired and configured. See the user manual for your intercom for more information. You can find the user manual at <i>help.axis.com</i> .			
The mobile app				
There are no notifications	Make sure you have turned on notifications in your mobile phone and in the app. See <i>Turn on notifications on page 25</i> for more information.			
I can't reach my site remotely	 Make sure you have the latest . Check that your mobile phone has internet connection via the mobile network or Wi-Fi. Log out from your Axis account and log in again to make sure you are correctly authenticated. 			

Save a system report



. In , go to Save system repo

2. When you register a new case at Axis Helpdesk, attach the system report.

Using devices with firmware 5.50

supports Axis devices with firmware 5.50 or higher. However, the 5.50 firmware is no longer supported by Axis and can't be upgraded. When using Axis products with 5.50 firmware, it is important to consider how various settings and situations can affect performance. An increasing number of connected clients, including audio, could impact performance. Devices running on 5.50 firmware in an system can show symptoms such as lagging video or long response time from the camera.

is a packaged solution. When a device is installed and added to a site, it is configured automatically for best performance. Therefore, it is highly recommended to use the default settings, i.e. continuous recording, not video motion detection.

If you still experience loss of performance, try the following to reduce the load on the device:

- 1. In , go to Cameras > Video quality.
- 2. Select the camera you want to configure..
- 3. Lower the camera resolution of the live and recorded video.

Troubleshooting

4. Lower the frame rate (FPS) of the live and recorded video.

Migrating from AXIS Companion Classic to

Requirements

If you are already using AXIS Companion Classic and want to upgrade to the latest version, read through the table below to confirm that your devices meet the requirements.

		AXIS Companion Classic	
Supported products	AXIS Companion IP cameras.	AXIS Companion IP cameras. Axis network cameras and encoders with firmware 5.50 and higher.	
	solutions that include an AXIS S30 Series Recorder support Axis cameras and encoders with firmware 5.50 or higher. solutions that don't include an AXIS S30 Series Recorder support Axis cameras and encoders with firmware 8.40 and higher. For more information, see <i>Using devices with firmware 5.50 on page 30</i> .		
	AXIS Companion Eye mini L, AXIS Companion Bullet mini LE and AXIS Companion Dome mini LE are only supported if they are connected to an AXIS Companion Recorder.		
Storage media	AXIS Surveillance Card	Axis SD card	
	AXIS Companion Recorder	AXIS Companion Recorder	
	AXIS S30 Recorder Series	AXIS S30 Recorder Series ¹	
	No third-party NAS support	Selected third-party NAS devices	
Multi-user support	Yes	No	
Alert notifications	Yes	No	
Remote system management	Yes	No	
Internet access	Required during system setup and management. Live and recorded video available offline.	Not required.	

¹ For information about limitations, see the technical paper 'Disclaimer - AXIS S3008 and AXIS Companion Classic' on axis.com/products/axis-companion-classic/support

Upgrade to

Note

- Any device that was used in AXIS Companion Classic must be hard reset or restored before it can be used in .
- A hard reset or restore of a device will not erase any recordings.

The installation wizard will detect if any devices need to be hard reset or restored, and assist you. If a device need to be restored, the wizard will take you to the device webpage, where you log in with the username ACCAdmin and the site password that you used in AXIS Companion Classic.

User manual
AXIS Companion
© Axis Communications AB, 2016 - 2024

Ver. M47.4

Date: April 2024

Part no. T10074276